

Combining Saorsat & Freesat Using 1 Dish & Offset Arm with 2 LNBS


Outside

Note: Ka Band LNB Should be Centred with Single Universal LNB to the Left



freesat
Single Universal LNB
is Pointed at
Astra2 @ 28.2 Degrees East

SAORSAT
Ka-Band LNB is Pointed at
Eutelsat @ 9 Degrees East



TV Rooms

Output from Diseqc Switch to LNB IN on DVB-S2 HD Satellite Receiver



Run HDMI or Scart Cable to your TV



Tutorial & Assembly Video Guides Available for all Associated Components
You can Find the Videos on the Individual Product Pages